

# WEttract

A Magnetic primer



Ready to use



Easy to apply



Versatile

WEttract is a light grey Magnetic Primer designed to make any surface into a Magnet attractive surface. WEttract can be applied to wood, metal, MDF, Cement Board, Mica, drywall, Gypsum Board, and can be coated over with any latex wall paint. Strong magnets with minimal weight adhere best when coated properly.

## TECHNICAL DETAILS

CHEMISTRY	Modified Alkyd System
USE	Interior, Exterior
VISCOSITY	Ready to use
FLAMMABILITY	Flammable
COVERAGE	10 SQFT Per Kg (2 Coat)
SOLVENT	Aromatic hydrocarbon, Ketone
VOC	<300 gm/Kg
METHOD OF APPLICATION	Roller, Brush
DRYING TIME	20 min Touch dry, Tack free 50 min
RECOAT TIME	After 20 min of first coat
THINNING	Do not thin or add any solvent
TEMPERATURE STABILITY	Dry heat up to 140 degree
SHELF LIFE (IN CONTAINER)	1 year in sealed can

## PRECAUTION

- Do WEttract application at temperatures between 15° C and 50° C and below 85% relative humidity.
- Do not add/mix colorants, solvent or water
- Ensure good ventilation during application and drying.
- Keep away from heat & Flame
- Avoid inhalation of vapors and contact with skin, eyes and clothing.
- Keep out of reach of children

## APPLICATION INSTRUCTION

- For best results, the surface should be as smooth as possible. Surface must be dust free, Clean and free from oil/grease.
- Magnetic Primer contain heavy particle. stir thoroughly for 3-5 minutes prior to application to ensure smooth, even consistency.
- Apply with Foam Roller for even coverage.
- It required 2 heavy wet on wet coat on surface to make it suitable for light weight magnets.
- Surface become touch dry after 20 minutes and ready to apply for 2nd coat of primer.
- After 4 hour, Any wall paint can be apply directly.

### TO APPLY LATEX PAINT

- After 4 hour of magnetic primer application, any latex wall paint can be apply directly with multiple coats until uniform coverage.

### TO APPLY WEPAIN WHITE

- Apply multiple coats of Latex white primer until uniform white colour. Allow it to dry for 24 hour. Then Apply WEPAIN White according to Instruction.

### TO APPLY WEPAIN CLEAR

- Any Coloured latex wall paint can be apply directly with multiple coats until uniform coverage. Allow it to dry for 24 hour. Then Apply WEPAIN Clear according to Instruction.
- Kindly refer to the MSDS which gives detailed information on safety measures while handling the paint, which is available on request.